






Switching Power Supply Accessories




Metal Mounting Brackets & Accessories

Part No.	Photo	Case No.	Applicable Models	Safety
DRL-01		238, 239, 240 903, 905, 931 932, 971	LRS-35/50/75/100 RS-25 RS-35 RS-15	
DRL-02		241 901, 902, 906 915, 916, 920	LRS-150/150F SD-100/150	
DRL-03A		980 987	SP-240 HRP(G)-300	
DRP-01		238, 239, 241 901, 902 903, 906 931, 932, 946	LRS-35/50/100/150/150F All models	
DRP-01A		203, 205 978, 999	RSD-100/150/200/300	
DRP-02		240 905, 915, 916, 920, 928	LRS-75	
DRP-03		DRP-01 DRL-01~03	All models	
DRP-04		203, 205 978, 999	RSD-100/150/200/300	
DRP-14		214 979 984	EDR/ NDR/ SDR/ TDR -240/ 480/ 960	
DRP-14A		214 CMU2	CMU2/ SDR-960/ TDR -960	
DRP-15		221 979, 984, 992	EDR/ NDR/ SDR/ TDR -75/ 120	


Part No.	Photo	Case No.	Applicable Models	Safety
MHS012		206, 207, 215A 912, 915, 916, 935, 939, 940 977, 980, 982, 986, 987, 995	HDP-190/ 240 RSP-150/ 200/ 320/ 500 RSP-2400/ 3000 SE-450/ 1000 MP450/ 650/ 1000 HRP-300/ 450/ 600 LRS-200/ 350/ 450/ 600 LRS-350N2/ 600N2	CE
MHS012LRS		207, 207A, 291, 292	NPB-120/240/360	
MHS012D		287	LRS-200/ 200N2 350/ 350N2 450/ 600/ 600N2	
MHS013		919, 926	SP-750 SE-600	
MHS013A		250 256 296 294	RSP-1600/ RPB-1600 RCP-1600/ RCB-1600 DPU-3200/ DRP-3200 NSP-1600/ NSP-3200	
MHS014		212 952	RSP-750 RSP-1000 SD-1000	
MHS025		910	PSP-600 SP-500 PSPA-1000	
MHS026		943	RSP-1500 / RST-7K5 / RST-15K / RST-10000 / BIC-5K / ERG-5000 / NTN-5K / SHP-30K	
MHS027		971, 931	RS12 RS25	

Installation Diagram

DRL/DRP series



MHS series



DRP series

